RPC units for BMS chambers



Outer layer

Inner layer

Sectors 2-4-6-8-10-16



Both layers

Sectors 12-14